

EDGE AND FACE INSTRUCTIONS

To begin Edge / Face mode:

- Send target to desired distance
- Press “Time (+)”
The “Time FOE” will come up on screen
- Enter desired target exposure time, in seconds, using the timer button keys – then press ENTER -
- Once you hit enter –
 - Target will immediately turn side ways for 2 seconds -
 - It will then face you for the programmed time
 - It will then return to the edge position.
- TO repeat the exercise:
 - Press the “Time (+)” ONCE –
 - Press ENTER –

 - Now the program will cycle again.

YOU MUST EXIT THIS ACTION BEFORE LEAVING SHOOTING BOOTH

To leave Edge / Face mode:

- Press “Time (+) ” button to return the time to -0-
- Press CLEAR –
- Press ENTER –
- Press FOE –